

GENERAL DESCRIPTION

The device DAT9000IO is an Intelligent unit able to control a network of slave Modbus RTU devices connected on serial line RS-485 Master executing the reading and writing of the field values and performing the logical and mathematical functions necessary for the system working

Moreover, the device is equipped with 4 digital inputs channels and 2 relay outputs . By means of the Ethernet interface or the RS-485 "SLAVE" or RS-232 ports it is possible to read and write, in real time, the internal registers value. Moreover, by means of the Ethernet interface, or by the RS-485 "SLAVE" or RS-232 ports it is possible to:

- Programming of the Control Logic

- Monitor, request of data, programming in real time the Intelligent Unit.

- Direct programming and request of data from the Slave devices connected on the RS-485 Master.

The device DAT9000IO is configurable by the software DEV9K, an easy and intuitive free IDE developed by DATEXEL and running under Windows.

The device DAT9000IO realizes a full electrical isolation between the lines, introducing a valid protection against the effects of all ground loops eventually existing in industrial applications.

LED signalling of Ethernet activity and data rx-tx flow on the serial line allows a direct monitoring of the system functionality. The connection is made by removable screw-terminals (supply and RS-485) and RJ45 plug (Ethernet and RS-232).

The DAT 9000IO is in compliance with the Directive 2004/108/EC on the electromagnetic compatibility.

The device is housed in a rough self-extinguishing plastic enclosure which, thanks to its thin profile of 22.5 mm only, allows a high density mounting on EN-50022 standard DIN rail.

LIST OF SUPPORTED FUNCTION

Communication:	- Read data from "slave" devices (Modbus function 04)		
	- Write data to "slave" devices (Modbus function 16)		

- Boolean(And, Or,) Logical:

- Compare (>, <, =,)

- Arithmetical (Sum, Subtraction, Multiplication, Division)

- Calculation (Scaling, Exponential functions, Square root extraction, Arithmetic mean,)

- Conditional statements (IF) Process:

- Flow control (Goto, Call,)

For the complete list of functions and their operation, refer to the Programming software User Guide.

TECHNICAL SPECIFICATIONS (Typical @ 25 °C and in the nominal conditions)

In compliance with Ethernet IEEE 802.3 EIA RS485 and RS232		Digital Inputs		Power supply	18 ÷ 30 Vdc
		Channels	4	Current consumption	45 mA typ. @ 24Vdc(standby) 100 mA max
Network interface Protocol RS485 Interface	Ethernet 10Base-T Modbus TCP	Input voltage OFF state ON state	(bipolar) 0 ÷ 3 V 10 ÷ 30 V	Isolations Power supply / Ethernet Power supply / RS485 Ethernet / RS485	1500 Vac, 50 Hz, 1 min. 1500 Vac, 50 Hz, 1 min. 1500 Vac, 50 Hz, 1 min.
Baud-rate	up to 38.4 Kbps	Impedance	4.7 ΚΩ	Inputs / RS485 Inputs / Power supply	2000 Vac, 50 Hz, 1 min. 2000 Vac, 50 Hz, 1 min.
Max. distance (recommended) (1)	1.2 Km @ 38.4 Kbps	Digital Outputs		EMC (for industrial environments)	
Number of modules		Channels	2	Immunity Emission	EN 61000-6-2 EN 61000-6-4
in multipoint	up to 32	Туре	SPDT Relays	Temperature & Humidity	
Internal termination resistance (optional)	120 Ohm	Switching Power (max.) 2 A @ 250 Vac (resistive load) per contact 2 A @ 30 Vdc (resistive load) per contact		Operative temperature Storage temperature Relative humidity (not cond.)	-20 ÷ +60 °C -40 ÷ +85 °C 0 ÷ 90 %
		Minimum load 5Vdc , 10mA Max. voltage 250Vac (50 / 60 Hz) , 30Vdc		Connections Ethernet RS-232D RS-485 / Supply	RJ-45 (on terminals side) RJ-45 (on front side) Removable screw terminals
		Dielectric strength between contacts 1000 Vac, 50 Hz, 1 min.		Housing	
(1) – The maximum distance depends of: number of devices connected, type of cabling, noises, etc		Dielectric strength between coil and contacts 4000 Vac, 50 Hz, 1 min.		Material Mounting Dimensions in mm.(WxHxT) Weight	Self-extinguishing plastic DIN rail EN-50022 100 x 120 x 22.5 about 160 gr.

INSTALLATION INSTRUCTIONS

The Intelligent Unit DAT9000IO is suitable for fitting to DIN rails in the vertical position.

For optimum operation and long life follow these instructions:

When the devices are installed side by side it may be necessary to separate them by at least 5 mm in the following case:

- If panel temperature exceeds 45°C and high power supply value(> 27Vdc).


Make sure that sufficient air flow is provided for the device avoiding to place raceways or other objects which could obstruct the ventilation slits. Moreover it is suggested to avoid that devices are mounted above appliances generating heat; their ideal place should be in the lower part of the panel. Install the device in a place without vibrations.

Moreover it is suggested to avoid routing conductors near power signal cables (motors, induction ovens, inverters, etc...) and to use shielded cable for connecting signals.

MODBUS REGISTERS MAPPING

Register Description		Access	
%S0	Reserved	R/W	
%S1	Firmware [0]	R	
%S2	Firmware [1]	R	
%S3	Name [0]	R/W	
%S4	Name [1]	R/W	
%S5	Port 1 [BaudRate]	R/W	
%S6	Node ID	R/W	
%S7	Port 1 [Timeout RX]	R/W	
%S8	Digital Inputs	R/W	
%S9	Digital Outputs	R/W	
%S10	System Flags	R/W	
%S11	Reserved	-	
%S12	Reserved	-	
%S13	PC	R	
%S14	Status [0]	R	
%S15	Status [1]	R	
%S16	COM Errors	R/W	
%S17	Gateway Mask [L-H]	R/W	
%S18	Port 0 [Settings]	R/W	
%S19	Port 0 [Settings]	R/W	
%S20	Timers Enable	R/W	
%S21	Reserved	-	
%R22	Reserved	-	
%R23	Reserved	-	
%R24	Reserved	-	
%R25	Reserved	-	
%R26			
	General	R/W	
	Purpose		
	Registers		
%R959			
%R960			
	Memory	R/W	
	Registers		
%R1023			

MECHANICAL DIMENSIONS (mm)



SERIAL PORTS RS-485 Slave (Port 0)

1

2

3


-

D +


GND

<u>WIRING</u>


RS-485 Master (Port 1)




RS-232D Slave (Port 0)





POWER SUPPLY





DIGITAL INPUTS





LIGHT SIGNALLING

LED	COLOR	STATE	DESCRIPTION
PWR	GREEN	ON	Device powered
		OFF	Device not powered / Wrong RS-485 connection
STS	YELLOW	BLINK	DEBUG modality
		OFF	RUN modality
RX n	RED	BLINK	PORT <i>n</i> – Data received (the blink frequency depends on Baud-rate)
		OFF	No reception in progress.
TX n	RED	BLINK	PORT <i>n</i> – Data transmitted (the blink frequency depends on Baud-rate)
		OFF	No reception in progress.
l n	RED	ON	State 1Digital Inputs.
		OFF	State 0 Digital Inputs.
O n	RED	ON	State 1Digital Outputs.
		OFF	State 0 Digital Outputs.

HOW TO ORDER

" DAT 9000IO "

ED.03.10 REV.00